


## L30WD Parts Breakdown

Click on any circled item, then add the part to your cart. If it won't click, the part is not available. If the part is not available, please call us at: 888.988.4546



| Item | Part No. | Name                                | Qty | Uom | NOTES |
|------|----------|-------------------------------------|-----|-----|-------|
| 1    | 32624    | HEATING ELEMENT                     | 1   | EA  |       |
| 2    | 33483    | THERMOSTAT                          | 1   | EA  |       |
| 3    | 10001    | BEZEL                               | 1   | EA  |       |
| 4    | 31419    | KNOB, BURNER                        | 1   | EA  |       |
| 5    | 32630    | HEAT ON LIGHT                       | 1   | EA  |       |
| 6    | 32217    | DRAWER SLIDE, 18" FULL<br>EXTENTION | 2   | EA  |       |
| 7    | 32634    | DRAWER HANDLE                       | 1   | EA  |       |
| 8    | 31736    | END CAP FDR HOOD<br>HANDLE          | 2   | EA  |       |
| 9    | 80826    | DRAWER ASSEMBLY                     | 1   | EA  |       |
| 10   | 32603    | STEAM PAN GUIDE                     | 1   | EA  |       |
| 11   | 32640    | STEAM PAN                           | 2   | EA  |       |
| 12   | 31967    | STEAM RACK                          | 2   | EA  |       |
| 13   | 32633    | STEAM PAN LID                       | 2   | EA  |       |
| NI   | 70078    | POWER CORD                          | 1   | EA  |       |