




Ref #	Part Number	Qty.	Description
1	A2008558		27 TOP REAR COVER
2	A2008543		TOP CHANNEL
3	PE050087		BLOWER ASSEMBLY - DESIGNER SERIES
4	A2008556		27 CABINET TOP
5	PJ030002		AUTO RESET (SELF-CLEAN) VDSC
6	A2009884		AUTO RESET BRACKET
7	PE070472		ELECTRONIC CONTROL BOARD
8	PE070147		TERMINAL BLOCK
9	A2007699		CABINET SIDE LH
10	A2006109		SELECTOR SWITCH COVER
11	A2007906		30`` SINGLE CAB. SIDE RH
12	PE050059		HI-LIMIT SWITCH
13	PE050112		DOOR LATCH
14	A2008526		SELECTOR BRACKET
15	A2009867		CLOCK MOUNTING BRACKET
16	PJ030030		4 POS SELECTOR SWITCH
	PJ030010		SELECTOR SWITCH (3-POSITION)VEDO205
17	PJ030001		SELECTOR SWITCH (8-POSITION) VDSC
18	PJ030037		SUB TO PS500033 - SELF CLEAN THERMOSTAT
19	PE050049		CLOCK/TIMER(ROBERTSHAWNO.100-00550-01 (BEFORE 02/27/06)
	PE050213		PRO 120V DIGITAL CLOCK (AFTER 02/27/06)
20	PE050019		OVEN LIGHT SWITCH (VGSO166) 90-DEG.
21	B92010566		27 DOUBLE CONTROL PANEL (BEFORE 02/27/06)
	C92010566BK		27 DOUBLE CONTROL PANEL XBK (BEFORE 02/27/06)
	C92010566WH		27 DOUBLE CONTROL PANEL XWHX (BEFORE 02/27/06)
	B92014944		27 DOUBLE CONTROL PANEL (AFTER 02/27/06)
	C92014944BK		27 DOUBLE CONTROL PANEL XBKX (AFTER 02/27/06)
	C92014944WH		27 DOUBLE CONTROL PANEL XWHX (AFTER 02/27/06)
22	PB010152		KNOB BEZEL-CHROME (30 B-IN OVEN)
	PB010153		KNOB BEZEL-XBRX (30 B-IN OVEN)
23	PB010165		TIME MANUAL KNOB XBKX (VESO/VEDO)
	PB010166		TIME MANUAL KNOB XWHX (VESO/VEDO)
24	PB010148		SELECTOR KNOB-XBKX (30DOUBLE OVEN)
	PB010149		SELECTOR KNOB-XWHX (30 B-IN OVEN)
25	PB010278		T/STAT KNOB-XBKX (B-IN OVEN)
	PB010279		T/STAT KNOB-XWHX (B-IN OVEN)
26	PB010248		CLOCK BUTTON
	PB010249		PUSH BUTTON WHITE
27	PB010246		CLOCK KNOB
	PB010247		KNOB WHITE
28	PE050024		OVEN IND. LIGHT (LIGHT HOUSING)
29	PE050023		OVEN IND. LIGHT (LENS & BEZEL)
30	PE040217		LOWER CONTROL PANEL EXTRUSION
NI	PE040069		SIDE TRIM-EXTRUDED (VEDO205)
NI	PE040218		CENTER EXTRUSION
NI	PE040219		BOTTOM TRIM
NI	PE040085		TOP EXTRUSION (27VESO/DO)




Ref #	Part Number	Qty.	Description
1	A2004308		TOP INSULATION RETAINER (27 OVEN)
2	PM010014		SMOKE ELIMINATOR (VDSC)
3	B2004311		BROILER TOP (27) (VESO176/DO276)
4	PJ010011		OUTSIDE BROIL ELEMENT (27 OVEN)240
5	PJ010001		BROIL ELEMENT 240V
6	B2002185		BROIL ELEMENT BRKT (VDSC)
7	A1004305		BACK INSULATION RETAINER(27OVEN)
8	A2002904		SIDE INSULATION RETAINER
9	A2002595		CONVECTION FAN BOX (VDSC)
10	PE050005		CONVECTION FAN ASSY
11	A1002596		CONVECTION FAN COVER (VDSC)
12	PJ010003		CONVECTION ELEMENT (VDSC) 240V
13	N/A		HEAT SHIELD - MUST ORDER ITEM NO. 11
14	N/A		HEAT SHIELD - MUST ORDER ITEM NO. 11
15	PJ010012		BAKE ELEMENT (VESO176/VEDO276)240V
16	PE050009		OVEN LIGHT SOCKET - 36 BUILT-IN
17	H9108575		27 UPPER FRONT FRAME ASSY
18	PC020016		HINGE RECEIVER (VEDO/VEDO)
19	PB060048		OVEN RACK - 27
20	PB060030		RACK SUPT REPL PB060010
21	E9104309		CONVECTION FAN COVER



Ref #	Part Number	Qty.	Description
1	H9108576		27 LOWER FRONT FRAME ASSY
2	PC020016		HINGE RECEIVER (VEDO/VEDO)
3	PJ010012		BAKE ELEMENT (VESO176/VEDO276)240V
4	PJ030022		HIGH LIMIT SWITCH
5	N/A		HEAT SHIELD - MUST ORDER ITEM NO. 11
6	N/A		HEAT SHIELD - MUST ORDER ITEM NO. 11
7	PE050009		OVEN LIGHT SOCKET - 36 BUILT-IN
8	E9104309		CONVECTION FAN COVER
9	PJ010003		CONVECTION ELEMENT (VDSC) 240V
10	A1002596		CONVECTION FAN COVER (VDSC)
11	PE050005		CONVECTION FAN ASSY
12	A2002595		CONVECTION FAN BOX (VDSC)
13	A2002904		SIDE INSULATION RETAINER
14	A2006088		OVEN MOUNTING BRACKET
15	PJ010001		BROIL ELEMENT 240V
16	PJ010011		OUTSIDE BROIL ELEMENT (27 OVEN)240
17	B2004311		BROILER TOP (27) (VESO176/DO276)
18	PM010014		SMOKE ELIMINATOR (VDSC)
19	A2004308		TOP INSULATION RETAINER (27 OVEN)
20	PB020117		DESIGNER OVEN VENT
21	PE050087		BLOWER ASSEMBLY - DESIGNER SERIES
22	A2007878		27 LOWER OUTER BACK
23	A1006115		LOWER REAR COVER 27
24	PB060048		OVEN RACK - 27
25	PB060030		RACK SUPT REPL PB060010




Ref #	Part Number	Qty.	Description
1	A2007878		27 LOWER OUTER BACK
2	A2007877		27 UPPER OUTER BACK
3	A2006180		DOUBLE OVEN FLUE COVER
4	A2006181		DOUBLE OVEN FLUE
5	A1006179		DOUBLE VENT COVER PLATE
6	A2006182		AIR SCOOP
7	A2006199		LOWER AIR VENT
8	A1006178		LOWER VENT COVER PLATE
9	A2006323		VENT SIDE RH
10	A2006324		VENT SIDE LH
11	A2006321		LOWER VENT SIDE RH
12	A2006322		LOWER VENT SIDE RH
13	A2006048		FAN MOUNTING BRACKET




Ref #	Part Number	Qty.	Description
NI	G3204337AL		UPPER DR ASSY XALX (VEDO276)
	G3204337ALBR		UPPER DR ASSY XAL/BRX (VEDO276)
	G3204337BK		UPPER DR ASSY XBKX (VEDO276)
	G3204337BKBR		UPPER DR ASSY XBK/BRX (VEDO276)
	G3204337BT		UPPER DR ASSY XBTX (VEDO276)
	G3204337BTBR		UPPER DR ASSY XBT/BR (VEDO276)
	G3204337BU		UPPER DR ASSY XBUX (VEDO276)
	G3204337BUBR		UPPER DR ASSYXBU/BRX (VEDO276)
	G3204337CB		UPPER DR ASSY XCBX (VEDO276)
	G3204337CBBR		UPPER DR ASSY XCB/BR (VEDO276)
	G3204337EP		UPPER DR ASSY XEPX (VEDO276)
	G3204337EPBR		UPPER DR ASSY XEP/BR (VEDO276)
	G3204337FG		UPPER DR ASSY XFGX (VEDO276)
	G3204337FGBR		UPPER DR ASSY XFG/BRX (VEDO276)
	G3204337GG		UPPER DR ASSY XGGX (VEDO276)
	G3204337GGBR		UPPER DR ASSY XGG/BRX (VEDO276)
	G3204337LE		UPPER DR ASSY XLEX (VEDO276)
	G3204337LEBR		UPPER DR ASSY XLE/BR (VEDO276)
	G3204337MJ		UPPER DR ASSY XMJX (VEDO276)
	G3204337MJBR		UPPER DR ASSY XMJ/BR (VEDO276)
	G3204337SG		UPPER DR ASSY XSGX (VEDO276)
	G3204337SGBR		UPPER DR ASSY XSG/BR (VEDO276)
	G3204337SS		UPPER DR ASSY XSSX (VEDO276)
	G3204337SSBR		UPPER DR ASSY XSS/BRX (VEDO276)
	G3204337VB		UPPER DR ASSY XVBX (VEDO276)
	G3204337VBBR		UPPER DR ASSY XVB/BRX (VEDO276)
	G3204337WH		UPPER DR ASSY XWHX (VEDO276)
	G3204337WHBR		UPPER DR ASSY XWH/BRX (VEDO276)
1	PB070034		INSULATION-TRS-10 1 X 20 X 3'
2	PB070038		TRS-10 2 X 24 X 3' INSULATION
3	A2002497		DOOR GUIDE ANGLE VDSC
4	PB070041		SUB TO 000623-000 - DOOR GASKET(3/8DIA.) (VDSC)
5	A2002367		DOOR GLASS BRKT
6	PE030001		BRACKET, DOOR, HANDLE
	PE030001PVD		END CAP DOOR HANDLE XBR
7	A2004332		DOOR INSULATION RETAINER (27OVEN)
8	G50010124		VESO176/VEDO276 DR LINER SVC-KIT
9	PB070040		FIBERGLASS ROPE
10	PE060023		HEAT TREATED DR GLASS(27WALL OVEN)
11	PC020188		DOOR HINGE
12	A2002960		HINGE BRACKET - LH (VEDO/VESO)
13	A2002962		HINGE BRACKET - RH (VEDO/VESO)
14	PE060050		J-MOLD XCHROMEX (27 OVEN)
	PE060051		J-MOLD XBRX (27 OVEN)
15	PE060022		OUTER DOOR GLASS (27 WALL OVEN)
16	B2004327		OUTSIDE DOOR PANEL(VEDO276)
	C9004327AL		UPPER OUTER DOOR PAN XALX(27OVEN)
	C9004327BK		UPPER OUTER DOOR PAN XBKX(27OVEN)
	C9004327BT		UPPER OUTER DOOR PAN XBTX(27OVEN)
	C9004327BU		UPPER OUTER DOOR PAN XBUX(27OVEN)
	C9004327CB		UPPER OUTER DOOR PAN XCBX(27OVEN)
	C9004327EP		UPPER OUTER DOOR PAN XEPX(27OVEN)
	C9004327FG		UPPER OUTER DOOR PAN XFGX(27OVEN)
	C9004327GG		UPPER OUTER DOOR PAN XGGX(27OVEN)
	C9004327LE		UPPER OUTER DOOR PAN XLEX(27OVEN)
	C9004327MJ		UPPER OUTER DOOR PAN XMJX(27OVEN)
	C9004327SG		UPPER OUTER DOOR PAN XSGX(27OVEN)
	C9004327VB		UPPER OUTER DOOR PAN XVBX(27OVEN)
	C9004327WH		UPPER OUTER DOOR PAN XWHX(27OVEN)
17	J1004330		DOOR HEAT SINK (VESO176/DO276)

Ref #	Part Number	Qty.	Description
17	J1004330		DOOR HEAT SINK (VESO176/DO276)
18	G50010124		VESO176/VEDO276 DR LINER SVC-KIT
19	E9102179		WINDOW LINER-SIDE (VDSC)
20	E9104331		WINDOW LINER-TOP/BTM(VESO176/DO276)
21	PE030074		DOOR HANDLE SS (27 WALL OVEN)
	PE030075		DOOR HANDLE BR (27 WALL OVEN)
NI	B1009167		HINGE CLIP




Ref #	Part Number	Qty.	Description
NI	G3204338AL		DOOR ASSY XALX (VESO176/DO276)
	G3204338ALBR		DOOR ASSY XAL/BRX (VESO176/DO276)
	G3204338BK		DOOR ASSY XBKX (VESO176/DO276)
	G3204338BKBR		DOOR ASSY XBK/BRX (VESO176/DO276)
	G3204338BT		DOOR ASSY XBTX (VESO176/DO276)
	G3204338BTBR		DOOR ASSY XBT/BRX (VESO176/DO276)
	G3204338BU		DOOR ASSY XBUX (VESO176/DO276)
	G3204338BUBR		DOOR ASSY XBU/BRX (VESO176/DO276)
	G3204338CB		DOOR ASSY XCBX (VESO176/DO276)
	G3204338CBBR		DOOR ASSY XCB/BRX (VESO176/DO276)
	G3204338EP		DOOR ASSY XEPX (VESO176/DO276)
	G3204338EPBR		DOOR ASSY XEP/BRX (VESO176/DO276)
	G3204338FG		DOOR ASSY XFGX (VESO176/DO276)
	G3204338FGBR		DOOR ASSY XFG/BRX (VESO176/DO276)
	G3204338GG		DOOR ASSY XGGX (VESO176/DO276)
	G3204338GGBR		DOOR ASSY XGG/BRX (VESO176/DO276)
	G3204338LE		DOOR ASSY XLEX (VESO176/DO276)
	G3204338LEBR		DOOR ASSY XLE/BRX (VESO176/DO276)
	G3204338MJ		DOOR ASSY XMJX (VESO176/DO276)
	G3204338MJBR		DOOR ASSY XMJ/BRX (VESO176/DO276)
	G3204338SG		DOOR ASSY XSGX (VESO176/DO276)
	G3204338SGBR		DOOR ASSY XSG/BRX (VESO176/DO276)
	G3204338SS		DOOR ASSY XSSX (VESO176/DO276)
	G3204338SSBR		DOOR ASSY XSS/BRX (VESO176/DO276)
	G3204338VB		DOOR ASSY XVBX (VESO176/DO276)
	G3204338VBBR		DOOR ASSY XVB/BRX (VESO176/DO276)
	G3204338WH		DOOR ASSY XWHX (VESO176/DO276)
	G3204338WHBR		DOOR ASSY XWH/BRX (VESO176/DO276)
1	PB070034		INSULATION-TRS-10 1 X 20 X 3'
2	PB070038		TRS-10 2 X 24 X 3' INSULATION
3	A2002497		DOOR GUIDE ANGLE VDSC
4	PB070041		SUB TO 000623-000 - DOOR GASKET(3/8DIA.) (VDSC)
5	A2002367		DOOR GLASS BRKT
6	PE030001		BRACKET, DOOR, HANDLE
	PE030001PVD		END CAP DOOR HANDLE XBR
7	A2004332		DOOR INSULATION RETAINER (27OVEN)
8	G50010124		VESO176/VEDO276 DR LINER SVC-KIT
9	PB070040		FIBERGLASS ROPE
10	PE060023		HEAT TREATED DR GLASS(27WALL OVEN)
11	PC020188		DOOR HINGE
12	A2002960		HINGE BRACKET - LH (VEDO/VESO)
13	A2002962		HINGE BRACKET - RH (VEDO/VESO)
14	PE060050		J-MOLD XCHROMEX (27 OVEN)
	PE060051		J-MOLD XBRX (27 OVEN)
15	PE060022		OUTER DOOR GLASS (27 WALL OVEN)
16	B2004326		OUTSIDE DOOR PANEL(VEDO276/VESO176)
	C9004326AL		OUTER DOOR PAN XALX (27OVEN)
	C9004326BK		OUTER DOOR PAN XBKX (27OVEN)
	C9004326BT		OUTER DOOR PAN XBTX (27OVEN)
	C9004326BU		OUTER DOOR PAN XBUX (27OVEN)
	C9004326CB		OUTER DOOR PAN XCBX (27OVEN)
	C9004326EP		OUTER DOOR PAN XEPX (27OVEN)
	C9004326FG		OUTER DOOR PAN XFGX (27OVEN)
	C9004326GG		OUTER DOOR PAN XGGX (27OVEN)
	C9004326LE		OUTER DOOR PAN XLEX (27OVEN)
	C9004326MJ		OUTER DOOR PAN XMJX (27OVEN)
	C9004326SG		OUTER DOOR PAN XSGX (27OVEN)
	C9004326VB		OUTER DOOR PAN XVBX (27OVEN)
	C9004327WH		UPPER OUTER DOOR PAN XWHX(27OVEN)
17	J1004330		DOOR HEAT SINK (VESO176/DO276)


Ref #	Part Number	Qty.	Description
17	J1004330		DOOR HEAT SINK (VESO176/DO276)
18	G50010124		VESO176/VEDO276 DR LINER SVC-KIT
19	E9102179		WINDOW LINER-SIDE (VDSC)
20	E9104331		WINDOW LINER-TOP/BTM(VESO176/DO276)
21	PE030074		DOOR HANDLE SS (27 WALL OVEN)
	PE030075		DOOR HANDLE BR (27 WALL OVEN)
22	PE010016		NAMEPLATE, LOGO, PRO
	PE010017		LOGO (VGSO,VEDO,VGDO,VUD) XWH/CHR
	PE010079		4.5 LOGO/VIKING PROF, BK/BR
	PE010080		4.5 LOGO/VIKING PROF XWH/BR
NI	B1009167		HINGE CLIP



Ref #	Part Number	Qty.	Description
-------	-------------	------	-------------



Ref #	Part Number	Qty.	Description
-------	-------------	------	-------------



Ref #	Part Number	Qty.	Description
-------	-------------	------	-------------
