



Ref #	Part Number	Qty.	Description
1	PB040130		90 DEG. (1/2) FEMALE ELBOW
2	PB010171		BEZEL - SS
	PB010172		BEZEL NEW BR REPL PB010107
3	B2003782		BOTTOM ISULATION SHIELD (VGSB121)
4	PA030002SS		BURNER BOWL (VGBQ) XSSX
5	B2003777		BURNER BOX BOTTOM (VGSB121)
6	B2003776		BURNER BOX SIDE (LH) (VGSB121)
7	B2003775		BURNER BOX SIDE (RH) (VGSB121)
8	B2003786		BURNER COVER (VGSB121)
9	PE030042		BURNER COVER HANDL.BBQ48/CHNO.P44-1010
10	B2003772		BURNER SUPPORT (VGSB122)
11	B9203783		CONTROL PANEL (VGSB12-1)
12	PK010048		DRIP TRAY HANDLE
13	B2003784		DRIP TRAY RUNNER (VGSB121)
14	B3003785		DRIP TRAY (VGSB12-1)
15	B2003538		FRONT SUPT (VGSB122)
16	PA080036		TOP BURNER REAR REPL PA080008
17	B2003771		GRATE SUPPORT (VGSB121)
18	B2001147		GRATE SUPT ANGLE (VGBQ) XSSX
19	PB010156		IGNITION SWITCH KNOB (BBQ GRILL) 1390-16
20	B2003778		ISLAND TRIM BACK (VGSB)
21	G3003787		ISLAND TRIM COVER ASSY (VGSB)
22	B1001138		MANIFOLD BRKT XSSX (VGBQ)
23	B2003507		MANIFOLD MOUNTING BRKT (FRONT)
24	B2003545		MANIFOLD MOUNTING BRKT (REAR)
25	PB040149		PIPE NIPPLE
26	B2003526		REAR SUPT (VGSB122)
27	PA050053		UNIVERSAL MANIFOLDXBUX
28	B2003773		SIDE PANEL (LH) (VGSB122)
29	B2003774		SIDE PANEL (RH) (VGSB121)
30	B2003780		SIDE TRIM (RH) (VGSB121)
31	B2003781		SIDE TRIM (LH) (VGSB121)
32	PA020022		SINGLE OUTPUT IGNITION SWITCH-(VGBQ (1691.06)
33	PA020028		SPARK IGNITER
34	PA010039		TOP GRILL KNOBxBKX (VGRC) (N/STYLE
35	PA010070		TOP BURNER VALVE (NAT.) (VGBQ)
	PA010069		TOP BURNER VALVE (LP) (VGBQ)
36	PA060030		V GRATE-VGRT XBKX
37	PK010047		12 LANDING LEDGE ASSY (VGSB)
38	PD030012		6-32 HEX NUT
39	PD010017		BALL STUD (VGRT)
40	PD010033		BALL STUD BRKT XSSX
41	PD040004		GROMMET BUMPER
NI	PD030050		10-24 CAGE NUT SS
NI	PD020062		NO.8-32 X 3/8 PHMS TYPE 1
NI	B2003350		SHELF GUSSET RH (BBQ)
NI	B2003269		SHELF GUSSET LH (VGBQ)